

INTEGRA IT-8000

Frequently Asked Questions

FEATURES

Q: Which connections are standard on the IT-8000?

A: The IT-8000 comes standard with the following connections: 24VAC/DC Power Supply, (2) isolated RS-485, Wi-Fi, 1 type A USB (Backup & Restore), 1 micro USB (Serial Shell), and (2) 10/100 Ethernet Ports.

Q: By upgrading to the IT-8000, can we move away from JAVA?

A: While Niagara 4 still utilizes JAVA technology, you no longer have to use JAVA as a Web visualization technology. Niagara 4 offers users the opportunity to choose open technologies such as HTML 5 when building/viewing information over the Web.

Q: Are any drivers included with the IT-8000?

A: Yes. Please refer to the list of Niagara 4 drivers, posted on the Dealer Toolbox. Additional Niagara or third-party drivers can also be added.

Q: Does the IT-8000 have RS-232?

A: RS-232 is available through an expansion module. The base IT-8000 does not have an RS-232 connection. If accessing serial shell, that can now be done through the micro-USB port on the IT-8000.

Q: Does every IT-8000 have Wi-Fi capability?

A: Yes, all IT-8000s come with Wi-Fi capability. 802.11a,b,g, and n networks are supported. Or, the IT-8000 can be ordered from American Auto-Matrix with Wi-Fi permanently disabled, if required.

Q: Is there an antenna option to get the wireless signals outside of a metal enclosure?

A: The antenna uses a standard SMA connector. An extension can be used to route the antenna and install outside of the enclosure.

Q: Can the IT-8000 be configured to automatically save the history trending data to the Supervisor computer?

A: Yes.

Q: Will existing NDIO modules work with the IT-8000, such as with some sort of adapter cable?

A: No. However, Niagara 4.1 has a tool to help convert NDIO points to an NRIO network. NRIO is compatible with the IT-8000.

Q: What Agency certifications does the IT-8000 meet?

A: The IT-8000 meets UL, CE, FCC, and numerous other standards. Please see the data sheet posted on the Dealer Toolbox for a complete list of certifications.

Q: What is the default IP address for all IT-8000 units?

A: 192.168.1.140

Q: Will an IT-8000 route IP data between Ethernet ports?

A: No.

SD CARD

Q: What is the onboard IT-8000 storage capacity of the SD card?

A: Each IT-8000 comes with a 4GB microSD card. User space is set at 2GB.

Q: Are you able to upgrade to a larger SD card for more space?

A: IT-8000 microSD cards will need to be purchased through American Auto-Matrix. This ensures that the IT-8000 performs as expected and has long life. AAM reserves the right to change the card capacity in the future.

Q: What happens if the microSD needs to be replaced?

A: American Auto-Matrix recommends that you utilize a Supervisor or new IT-8000 USB Back-Up & Restore to backup your IT-8000 periodically. Similar to a Niagara AX today, licenses can be transferred over to new hosts and a backup dist can be loaded. Contact Inside Sales for replacement SD cards.

Q: Can an SD card Host ID be generated on an engineering laptop and then transferred to the IT-8000?

A: No.

Q: Can the license, station and drivers be transferred from one IT-8000 to another via the microSD card?

A: Yes. The new IT-8000 will need the system password from the old IT-8000.

VOLTAGE

Q: What input power does the IT-8000 need?

A: The IT-8000 accepts 24VAC/DC without additional modules. Tridium offers a standard line voltage adapter (WPM-8000) for the IT-8000.

USB

Q: Can I use a USB flash drive with my IT-8000?

A: Yes. After inserting a USB flash drive, you can do a complete station backup or restore. See IT-8000 documentation for additional details.

Q: Using the USB flash connection, would we be able to export history to an external drive in real time?

A: The USB connector is defined for temporary use and not meant to support permanently installed storage.

LICENSING

Q: How is the IT-8000 licensed?

A: All IT-8000s come licensed by devices and points. After determining how many devices will be integrated into the IT-8000, select the license with the appropriate amount of capacity. For example, if you are integrating 20 BACnet, 10 LON and 10 Modbus devices, the NC-8050 device core could be selected to support up to 50 devices.

Q: How will using the IT-8000 in Niagara AX be licensed — by Devices or Resources?

A: The IT-8000 will initially be available with Niagara 4.1. We are looking to release a 3.8U build in the future that will offer IT-8000 support. Similar to Niagara 4, the IT-8000 will be licensed by devices and points.

Q: With the Device/Point licensing, are they both hard limits? For example, 8010 can support 10 devices or 500 points. Is there flexibility to exceed one of those limits? For example, 12 devices with 10 points each?

A: The IT-8000's device/point license applies to which limit you reach first. In the example above, 12 devices exceed the 10-device limit, even though only 120 points were used. The device/point license are hard limits, however upgrade packs will be available to upgrade the license.

Q: Will my Integra 300-E, 600-E or 700, have device/point limits if upgraded to Niagara 4?

A: No.

Q: On licensing, will it still be possible to upgrade an existing license to a license with more capacity? For example, if a project is expanded during construction.

A: Yes, upgrade device/point packs are available. Contact Inside Sales for details.

Q: Will the points being used by the IT-8000 be viewable?

A: Yes. Station summaries can be viewed from the resource manager.

Q: What are the device and point packs being offered?

A: The IT-8000 is available with 5, 10, 25, 100 and 200 device base licenses. Additional device/point upgrades can be added to any base license. They are available in 10, 25 and 50 device upgrade packs.

UPGRADE PACKS

Q: Is there a limit to how many Device upgrade packs I can add to an IT-8000?

A: While there isn't a hard limit on the number of upgrade packs that can be added, users should monitor CPU utilization, heap usage and integration bus limits when adding device upgrades.

Q: If we have an 8200, and we have 200 controllers connected, can we add one additional controller without another device? Or are we absolutely locked to controller number?

A: Upgrade packs are available to enable more than 200 devices.

MAINTENANCE

Q: When does software maintenance start on the IT-8000?

A: Software maintenance starts when the Integra software license is purchased. Please see your distributor for details.

Q: Is Maintenance and Warranty the same thing?

A: No. Software maintenance enables access to the latest Niagara build with new features and software updates. Warranty covers the IT-8000 from manufacturing defects.

Q: Does the IT-8000 automatically include maintenance at the time of purchase?

A: Yes, it includes 18 months from the date of the creation of the license, when bundled with the INIT license part. Initial maintenance is a separate line item that must be chosen while purchasing.

Q: Can I buy more than 1-year maintenance at a time?

A: Yes. SMA can be purchased for 1, 3 or 5 year periods.

Q: How will multiple quantities of maintenance appear on a license?

A: Dates will run consecutively (i.e. buy qty 2 = 2 yrs). Date will show in license header details and in license view.

Q: What if I choose not to renew my Niagara 4 maintenance?

A: If the SMA has expired on the IT-8000, it will continue to run the station. However, the device will not have access to any new versions, update builds or patches for Niagara 4. Gap charges will apply if you choose to renew once the SMA has expired.

MIGRATION

Q: How do I take my IT-300-E, IT-600-E and IT-700 up to Niagara 4? How do you buy it when you're rolling out a new software maintenance policy?

A: Pre- and post-Niagara 4 release, you will need to add a maintenance part to existing Niagara AX Integra devices to upgrade licenses to Niagara 4.

Q: Would you be able to revert back to Niagara AX from Niagara 4 if you wanted to?

A: The conversion disk file will clean it and convert back to the Niagara AX system. Niagara Central will host both Niagara AX and Niagara 4 licenses.

Q: When migrating from Niagara AX to Niagara 4, should you start by upgrading the existing Integra hardware first?

A: No, you should upgrade the Integra Supervisor to Niagara 4 first.

Q: Which Integra devices can be updated to Niagara 4?

A: The IT-300E, IT-600E and IT-700 platforms can be updated to Niagara 4.

Q: Can I have a mixed Niagara AX / Niagara 4 job?

A: Yes, however the Supervisor needs to be at highest version.

OPTION MODULES

Q: How many accessory cards, or expansion modules, can we add?

A: Up to 4 in various combinations. See the data sheet posted online at <http://www.aamatrix.com/products/integra-it8000> for additional details.

Q: Will we have the ability to place the modular expansion cards on a bus? Or do they have to "snap" together?

A: Option modules will need to be directly connected to the IT-8000.

Q: Which option card modules will be available at launch?

A: The NPB-8000-2X-485, NPB-8000-LON and NPB-8000-232 will be available at launch.

Q: Is there a plan to port third-party option modules?

A: While not available at launch, an expansion module is planned for release. Stay tuned to future announcements about IT-8000 accessories.

Q: How many LON Option Module cards can be attached to the IT-8000?

A: Up to 4 can be attached.

ORDERING

Q: Can an IT-8000 for Niagara 4 be downgraded to Niagara AX 3.8?

A: Yes, once Niagara AX 3.8U that supports the IT-8000 is released.

Q: If I don't use all the devices I purchased, can I transfer the device to another license?

A: No. Unless ordering a replacement unit, unused license elements cannot be transferred.

Q: Can I still order Niagara AX Integra Controllers?

A: Yes, they will ship licensed for 3.8, and you would need to purchase maintenance to upgrade to Niagara 4.

Q: How do I buy drivers for an IT-8000?

A: Open drivers are now included, and a list of Niagara 4 drivers is posted online at <http://www.aamatrix.com/products/integra-it8000>. Any additional boutique drivers will be purchased ad hoc as before, though global capacity limits apply to all drivers used on the IT-8000.

Q: How can I buy the IT-8000?

A: Tridium offers multiple options for purchasing IT-8000s. Hardware and software can be bundled together or separately. Also, you can add capacity later, as needed. Please contact Inside Sales for details.

WARRANTY

Q: When does the warranty start on the IT-8000?

A: The hardware warranty starts when shipped from American Auto-Matrix. For all Integra products, the warranty covers 18 months.

Q: If the hardware fails, what is the warranty process?

A: Please contact Inside Sales for details.